



Skyline

Book Binding Machines & Supplies

Sales • Service • Repair


Professional Service – Fast Nationwide Shipping

1-866-455-9900

www.OnlineSkyline.com CustomerService@onlineskyline.com


ES8000 Part Catalogue - EXTERIOR UNIT

NO	Part Number	Part Name
10	PM3SE-1003	COVER:FRONT:ASSY
20	PM3SE-1001	COVER:REAR
25	SEL-0091	REAR COVER FRANGE
30	PM6-A006	TOP COVER
40	PM3SE-1006	COVER:FRONT:OP
50	PM6-A009	COVER:FRONT
60	PM3SE-1004	COVER:TOP:MIDDLE
70	ECB-0002-2	SMPS(AC 115V)
80	ECB-0004-3	MAIN BOARD : ES8000
90	APP-0014-1	FRAME:KEY-MP
100	PM6-A008	COVER:OP
110	APP-0015-4	WINDOW:OP:ES8000
130	PM6-U102	Shield:Lower:2PR
131	LCT-0038	BKT:WIRE:FIX
135	LCA-0028	MAGNET
140	PM6-U101	Shield:Upper:2PR
160	APP-0013	Wire Protect:Sealer Exit
166	APP-0093	LATCHET TOOL
167	SEL-0092	JAM REMOVAL HANDLE BUSH
1100	LCA-0032	Plate Support
1110	LCA-0031	Plste Support_1




ES8000 Part Catalogue - FOLDING UNIT

NO	Part Number	Part Name
1200	FOL-ES80	ES8000 FOLD ROLLER SET
170	FOL-0004	ROLLER:IDLE
180	PM3SE-2002_A	ES8000:ROLLER:FOLDER:2ND
190	PM3SE-2001	ES8000:ROLLER:FOLDER:1ST
200	FOL-0009	ROLLER:FOLDER:4TH
210	FOL-0007	BKT:TENSIONER
220	FOL-0005	BUSHING SPRING
221	FOL-0006	SPRING:COMPRESSION:UPPER
222	FOL-0030	STEP SCREW
230	FOL-0006-A	SPRING:COMPRESSION:LOWER
240	FOL-0002	SPRING:EXTEND
250	OPEN-1042	Ball Bearing_NMB_F688ZZ
1100	PM6-D010-A	FOLDER ROLLER GEAR ASS`Y
260	PM6-D010	FOLDER ROLLER GEAR
265	WEL-B350-00	CLUTCH BEARING-CHI
786	LCT-0043	LCT:COMPRESSION SPRING




ES8000 Part Catalogue - FRR

NO	Part Number	Part Name
270	FRR-0001	FRAME:FRONT:FRR
280	FRR-0002	FRAME:REAR:FRR
285	FRR-0039	STUD:FRR
290	FRR-0003	GUIDE:FEED:UPPER
300	FRR-0035	GUIDE:FEED:LOWER
310	PM6-T013	PM6:ACTULATOR:TRAY
315	FRR-0025	PIN:ACTULATOR
320	FRR025SR	SNAP RING
350	FRR026SY	PICK-UP IDLE GEAR 15T
360	PM6-R050_A	SHAFT:FEED
370	FRR-0046	BUSHING:φ8
380	FRR-0907	DU BUSHING:0806F
390	FRR-0013	ACTUATOR:PAPER
400	FRR-0038	ASS'Y BKT:PICK-UP
410	FRR-0037	BKT:STOPPER:CLUTCH
420	FRR-0057	ONE-WAY:BEARING ASS'Y
582	FRR-0060	ONE-WAY:BEARING:BUSH
583	WEL-B350-02	CLUTCH BEARING-CHI(INSET-MOLD)
430	FRR020DY	CLUTCH:FEED
440	FRR-0050	SPRING:EXTEND:FRR
460	FRR015HS	SENSOR:PID
470	SEL-11050231	CLAMP(S):MICRO WIRE SADDLE-2N
500	FRR-0056	BUSH:FRR
505	FRR-0043	SPRING:FRR
510	FRR-0053	SUPPORT BLADE
515	FRR-0055	PM3:FAN:BRKT
520	ECB-0003-20	FAN HARNESS
530	FRR-0016	SHAFT:FRR
540	FRR-0017	SHAFT:IDLE:FRR
550	FRR-0021	GEAR:Z20:FRR
560	FRR-0022	GEAR:Z16:FRR
570	LCA-0029	BUSHING:φ6
580	FRR-0023	GEAR:27T:IDLE
585	UCA-0020	SENSOR:R50
1210	ECB-0004	DF SENSOR SET
450	ECB-0004-1	THICKNESS SENSOR (T)
455	ECB-0004-2	THICKNESS SENSOR (R)
1220	INF-P301	P3 INFEEED ROLLER SET
330	FRR009SR-1	PICK-UP ROLLER RUBBER
335	FRR009SR-2	PICK-UP ROLLER HUB
340	FRR-1201	FEEDING ROLLER RUBBER
345	FRR-1202	FEEDING ROLLER HUB
480	FRR-1302	S/P ROLLER HUB
485	FRR-1301	S/P ROLLER RUBBER
490	FRR-1401	S/P ROLLER(TORQUE LIMIT)
583	WEL-B350-01	CLUTCH BEARING CHI




ES8000 Part Catalogue - LCA

NO	Part Number	Part Name
220	LCA-0002_C	GUIDE:2ND FOLDER:LOWER:ASS'Y
221	LCA-0022	BKT:FRONT GUIDE:ASS'Y
230	LCA-0003_C	GUIDE:3TH FOLDER:LOWER
240	LCA-0021	BKT:RAIL:2ND FOLDER
250	PM6-L001	PM6:STAY:2ND FOLDER
260	PM6-L010	SLIDE RAIL S27PD-400
272	PM6-L044	NORD LOCK
273	PM6-L042	KNOB:FOLDER SCREW:LOCK
274	PM6-L043	CAP NUT
1270	LCA-A001	LCA ACME BLOCK ASS'Y
270	PM6-L105	BLOCK:FOLDER SCREW
271	LCA-0029	BUSHING:φ6
275	PM6-L045-1	ROLLER:IDLE:LCA
280	LCA-0033	BLOCK:ACME THREAD
281	UCA-0007	STOPPER BLADE
282	UCA-0904	RUBBER DAMPER (L)
283	UCA-0903	RUBBER DAMPER (S)
290	LCA-0011	BKT:MAGNET:2ND FOLDER
291	LCA-0028	MAGNET
300	LCA-0010	BKT:I/L:2ND FOLDER
301	LCT-0027	MICRO S/W
310	LCA-0040	V-FOLD GUIDE




ES8000 Part Catalogue - UCA

NO	Part Number	Part Name
271	LCA-0029	BUSHING:φ6
272	PM6-L044	NORD LOCK
273	PM6-L042	KNOB:FOLDER SCREW:LOCK
274	PM6-L043	CAP NUT
281	UCA-0007	STOPPER BLADE
282	UCA-0904	RUBBER DAMPER (L)
283	UCA-0903	RUBBER DAMPER (S)
291	LCA-0028	MAGNET
440	UCA-0002	GUIDE:LOWER
450	UCA-0026	UCA SUPPORT:BKT
460	UCA-0041	GUIDE:UPPER:M TYPE
470	UCA-0043	COVER:UCA
471	PM6-U032	UCA HADLE
480	PM6-U101	Shield:Upper:2PR
481	PM6-U030	PM6:SHAFT:FIX:WIRE
482	DS-8015	Antistatic Brush (240mm Hole)
500	PM6-U021	PM6:SHAFT(L):HINGE
510	PM6-U010	PM6:UCA:BLOCK
511	PM6-U020	PM6:STEP SCREW
512	PM6-U023	PM6:STOPPER
513	PM6-U022	PM6:SHAFT(S):HINGE
1250	UCA-A001	UCA ACME BLOCK ASS'Y
271	LCA-0029	BUSHING:φ6
490	PM6-U105	SCREW:ACME THREAD:UCA
491	PM5-1333	ROLLER:IDLE:UCA
515	PM6-U112	BLOCK:ACME THREAD:UCA




ES8000 Part Catalogue - LCT

NO	Part Number	Part Name
690	LCT-0042	ASS'Y TRAY:BASE:LCT
695	LCT-0002	BKT:BASE:SUPPORT:FRONT
696	LCT-0013	BKT:BASE:SUPPORT:REAR
700	LCT-0040	ASS'Y TRAY:FRONT:LCT
705	LCT-0041	ASS'Y TRAY:REAR:LCT
710	LCT-0008	SHAFT:TRAY:FIX
711	LCT-0009	KNOB:TRAY:FIX
715	LCT-0007	BKT:SLOT:FIX
720	LCT-0010	ASS'Y:BKT:RAIL:FRONT
721	LCT-0004	ROLLER:RAIL
725	LCT-0036	ASS'Y:BKT:RAIL:REAR
730	LCT-0003	BKT:SLOT
740	PM6H-L017	PM6:BKT:FRONT:BASE
745	PM6H-L018	PM6:BKT:REAR:BASE
750	PM6H-L016	BKT:REAR:HOLDER:HD
760	LCT-0023	ASSY:BKT:PULLEY
770	LCT-0030	BKT:S/W
780	LCT-0016	SHAFT:DRIVE:LCT
781	LCT-0022	PULLEY:S3M20T
782	LCT-0018	FRANGE:PHI8
783	LCT-0015	BELT:B60S3M453
784	LCT-0021	GEAR:Z60
785	UCA-0905	WASHER M6(ϕ 12.5, 0.5t)
786	LCT-0043	LCT:COMPRESSION SPRING
790	LCT-0017	BKT:DC MOTOR
791	LCT-0026	MOTOR:DC 24V
792	LCT-0019	SHAFT:GEAR
793	LCT-0020	GEAR:Z65/Z20
800	LCT-0038	BKT:WIRE:FIX
810	LCT-0025	SHAFT:TRAY, WIRE



ES8000 Part Catalogue - SEALER

NO	Part Number	Part Name
1250	PM6-S001-A	UPPER BLOCK ASS`Y
880	PM6-S001	PRESS BLOCK:UPPER
885	SEL-0002A	BEARING:SEALER(6004Z)
1260	PM6-S121-A	LOWER BLOCK ASSS`Y
890	PM6-S121	PRESS BLOCK:LOWER
885	SEL-0002A	BEARING:SEALER(6004Z)
895	SEL-0011	SPRING:SH16X25
900	PM6-S004	FRAME:SUPPORT
905	SEL-1005	GEAR BOX 5:1
906	SEL-1008A	MOTOR(115V, 90W, 60Hz)(UL)
910	SEL-0001-1	PRESS ROLLER(UPPER)
911	SEL-0023	KEY:SQ6X12
915	SEL-0001-2	PRESS ROLLER(LOWER)
916	SEL-0023-1	KEY:SQ6X25
920	PM6-S042	PM6:GEAR:SEAL:70T
925	SEL-0007	Pulley:S5M35T
926	SEL-0014	TIMING BELT S5M350
928	SEL-0093	JAM REMOVAL HANDLE SPRING
930	SEL-0009	PULLEY:S5M24T
931	FOL-0008	BELT:MB360
932	SEL-0015	V-PULLE:Sealer



ES8000 Part Catalogue - FRAME

NO	Part Number	Part Name
665	LCT-0027	MICRO S/W
940	PM6-F002	FRAME:FRONT
945	FRA-0018	BKT:HINGE:TOP COVER
950	PM6-F004	FRAME:REAR:ASS'Y
955	FRA-0020	BKT:REAR COVER SET
960	FRA-0001	FRAME:BASE
965	FRA-0004	BKT:FRAME:FABRICASION
966	FRA-0024	FOOT
970	FRA-0005	SHAFT:SUPPORT
990	FRA-0006	SEALER GUIDE:FOLDER OUT:UPPER
995	TRN-6480	SENSOR:R11
1000	FRR-0011	BKT:SHIELD:LOWER
1010	FRA-0019	PLATE SPRING:TOP COVER
1015	PM3-U999	TOP COVER:DAMPER
1030	FRA-0022	BKT:HARNESS
1040	FRA-0012	LEVER:I/L:TOP COVER:LCT:ASS'Y
1041	FRA-0011	ACTUATOR:I/L:TOP COVER
1045	FRA-0014	LEVER:I/L:TOP COVER:FOLDER:ASS'Y
1050	FRR-0030	GEAR/PULLEY:FRR
1055	FRR-0032	BELT:B60S3M225
1300	PM6-F200	V-PULLEY/GEAR ASS'Y
1070	PM6-S112	TRANSFER GEAR:ASS'Y
1071	OPEN-1062	Ball Bearing 608Z
1072	BEN010DJ	Bearing:F688ZZ
1081	PM5-8040	S/W R19-20BG
1082	PM5-5508	Fuse Holder
1085	PM6-F031	AC SOCKET(RICH BAY R-3012)
1090	LCA-0030-2	SNAP BUSHING(DASB-750-10)
1120	PM6-F033	KEPB16ER-R1B (Switch)
1200	PM3SE-F035	PM3SE:HARENSS:NOISE FILTER

