

Sales • Service • Repair

Professional Service – Fast Nationwide Shipping

1-866-455-9900



This is a guide for adjusting the potentiometers on 5009, 8x40-80mm

First press and hold the REVERSE button, adjust R48 CLOCKWISE until yellow LED on LEFT on the pcb goes out, continue watching the LED that it stays out.

Press the FORWARD button, the machine should be running on LOW speed. Adjust R48 COUNTER-CLOCKWISE until machine goes to HIGH speed, add 1/2 rotation.

Take 250 sheets, 20lb, 8 ½" x 11" paper, machine jams and goes to LOW speed. If not adjust R45 COUNTER-CLOCKWISE 1/4 to 1/2 revolution and re-check.

Take 500-600 sheets, 20lb, 8 ½" x 11" and test that machine goes to LOW speed, STOPS, REVERSES, then goes FORWARD, if it does NOT, turn R42 in 1/4 to 1/2 turns COUNTER-CLOCKWISE, and retest.

This supercedes any prior information. JAC102805.

SHREDDERS

CUTTERS

TRIMMERS

FOLDERS

COLLATORS

BOOKLETMAKERS

SUPPORT PRODUCTS

3134 Industry Drive

North Charleston

South Carolina 29418

800-223-2508

Fax: 843-552-2974

www.mbmcorp.com